拆除或更换交换机后持续存在的交换机运行状况警报

适用于

- ONTAP
- 集群交换机

问题描述

- 删除后，集群交换机存在交换机健康警报

```
Cluster::> system health alert show
              Node: Cluster-02
```

示例：

```
      Alert ID: SwitchSSHAccess_Alert

   Alert ID: SwitchInfoUpdateFailure_Alert

         Resource: Old-Cluster-SW2 (XX:XX:XX:XX:XX:XX)
```

- 已删除交换机的健康警报。

```
::*> system health subsystem show Subsystem Health ---------------- -----
------------- SAS-connect ok Environment ok Memory ok Service-Processor
ok Switch-Health degraded CIFS-NDO ok Motherboard ok IO ok MetroCluster
ok MetroCluster_Node ok FHM-Switch ok FHM-Bridge ok SAS-connect_Cluster
ok 13 entries were displayed.
```

::*> system health subsystem show -subsystem switch-Health Subsystem: Switch-Health Health: degraded Initialization State: initialized Number of Outstanding Alerts: 4 Number of Suppressed Alerts: 0 Node: switch1 Subsystem Refresh Interval: 5m

- 交换机被删除后不再显示

  ○ ONTAP 9.8 及更高版本 - ::>system switch ethernet delete -device Old-Cluster-SW2

  ○
```
             ::>system switch ethernet show

         Error: There are no entries matching your query.
```

  ○ ONTAP 9.7 及更低版本 - ::>system cluster-switch delete -device Old-Cluster-SW2

  ○
```
             ::>system cluster-switch show

         Error: There are no entries matching your query.
```