



## 由于电池故障、E系列控制器处于代码为SE 88或88的锁状态

[https://kb-cn.netapp.com/on-prem/E-series/Hardware-Kbs/E-Series\\_controller\\_in\\_lockdown\\_with\\_code...](https://kb-cn.netapp.com/on-prem/E-series/Hardware-Kbs/E-Series_controller_in_lockdown_with_code...)

Updated: Thu, 16 Apr 2026 02:14:49 GMT

### 适用场景

NetApp E系列硬件

### 问题描述

控制器处于7段代码SE 88或仅88的锁止状态。启动开始时、输出顶部将显示以下错误消息。

```
ERROR: CLASS: 3000000; SUBCLASS: 60000; OPERATION: A
```