



离线更换扩展架后, E系列 WWN 发生变化

 $https://kb-cn.netapp.com/on-prem/E-series/SANtricity-OS-Kbs/E-Series_WWN_changed_after_offline_r...$

Updated: 周五, 11 7月 2025 08:19:23 GMT

适用场景

- NetApp E 系列
- 设置包括扩展托盘。

问题描述

- 冷更换扩展架 0 后,两个控制器的所有 BASE 和主机接口卡 (HIC) 端口的 FC 目标端口 WWN 均发生变化。
 - 。 冷更换意味着控制器托盘已断电以完成扩展托盘的更换。

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information contained herein may be used solely in connection with the NetApp products discussed in this document.'