



NiCE

AFF A90 节点未通电

https://kb-cn.netapp.com/on-prem/ontap/OHW/OHW-KBs/AFF_A90_node_not_powering_on

Updated: Tue, 14 Jul 2026 12:33:53 GMT

适用于

- ONTAP 9
- AFF A90

问题

- 此节点未通电。
- 尝试通过 BMC 为节点通电时失败。

```
BMC> system power on
..
BMC> system power status
Host power is off
```

- 重新拔插主板后，问题仍然存在。
- 主板已更换，但节点仍无法通电。

```
BMC node1> system power status
Host Power is off
```