



---

## 在HCI系统上反复出现自解析电源输入缺失或超出范围警报

[https://kb-cn.netapp.com/on-prem/SolidFire/Element\\_OS\\_Kbs/Repeating\\_self\\_resolved\\_power\\_supply...](https://kb-cn.netapp.com/on-prem/SolidFire/Element_OS_Kbs/Repeating_self_resolved_power_supply...)

Updated: Thu, 16 Apr 2026 13:35:57 GMT

### 适用场景

- NetApp Element软件12.2、12.3.x
- NetApp H410S
- NetApp H610S

## 问题描述

- SolidFire Active IQ显示重复的 `powerSupplyError - Power supply PSx input missing or out of range`. 警报、一分钟左右即可解决
- IPMI上的“传感器读数”页面(IPMI、服务器运行状况、传感器读数) 在所有传感器或两个电源的 `Not PresentReading` 电源)列显示为 ”