



" (CHASSIS POWER DEGRADED: Power Supply Status Critical: PSU1, PSU2.)ERROR" AutoSupport 消息发生

https://kb-cn.netapp.com/on-prem/ontap/OHW/OHW-KBs/CHASSIS_POWER_DEGRADED__Power_S...

Updated: Sat, 25 Apr 2026 00:03:21 GMT

适用于

- FAS2620
- FAS2720
- FAS2750
- FAS8200
- AFF A300

问题

- 触发 **AutoSupport**，机箱电源已降级。

```
HA Group Notification from node-02 (CHASSIS POWER DEGRADED: Power  
Supply Status Critical: PSU1, PSU2.) ERROR
```

- 以下消息显示在 **EMS-LOG-FILE.GZ** 中

```
[node-02: monitor: monitor.globalStatus.critical:EMERGENCY]: Power  
Supply Status Critical: PSU1, PSU2.  
[node-02: power_low_monitor: monitor.chassisPowerSupplies.ok:info]:  
Chassis power supplies OK  
[node-02: monitor: monitor.globalStatus.ok:info]: The system's global  
status is normal
```

- 运行命令 [system chassis fru show](#) 或 [system controller fru show](#) 以检查状态