



由于 ex=xYourBinAssignmentsOutOfDate, 阻止驱动器进入可用状态

https://kb-cn.netapp.com/on-prem/SolidFire/Element_OS_Kbs/Block_drive_goes_into_the_available_st... Updated: Mon, 27 Oct 2025 04:06:49 GMT

适用于

- SF19210
- NetApp Element 软件

问题描述

- 一个块驱动器变为可用状态。
- 以下事件检测于 sf-slice.log
 - 2021-03-01T20:22:17.119285Z AMS01-SF19210-01 block1570[26724]:
 [UNEXPERR-2] [Blocks] 35679 BSOpQueueWr-1570 bs/
 GenLogBSData.cpp:956:WriteBlockAsync|[#### SUPPRESSED 2X ####]

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information contained herein may be used solely in connection with the NetApp products discussed in this document.'

```
myServiceID=1570Failed Write
writeBlock=[blockID=b112bcee59153ab12e2a0ce26bccab4d
dataPtr=0x7f3bae801ca4 protectionSchemes={doubleHelix}
bsWriteType=Flush] ex=xYourBinAssignmentsOutOfDate at virtual
solidfire::MasterVersionReadLock
solidfire::BSBinAssignmentsTracker::GetMasterVersionReadGuarantee(int)
(bs/BinAssignmentsTracker.cpp:48): xYourBinAssignmentsOutOfDate
```