



SG6000 连续重启，并显示消息"hostbyte=DID_NO_CONNECT"

https://kb-cn.netapp.com/hybrid/StorageGRID/Platforms/SG6000_Reboot_Loop___hostbyte_DID_NO_...

Updated: Thu, 16 Apr 2026 19:42:38 GMT

适用于

- NetApp StorageGrid SG6000
- 固件版本 11.3

问题

- SG6000 处于引导循环中
- 到后端存储的路径丢失
- 每次重启循环后，在虚拟控制台或串行连接中会看到以下事件：

```
sd 16:0:0:251: [sdp] Synchronizing SCSI cache
sd 16:0:0:251: [sdp] Synchronize Cache(10) failed: Result:
hostbyte=DID_NO_CONNECT driverbyte=DRIVER_OK
scsi 16:0:0:251: rdac: Detached
sd 16:0:0:252: [sdq] Synchronizing SCSI cache
sd 16:0:0:252: [sdq] Synchronize Cache(10) failed: Result:
hostbyte=DID_NO_CONNECT driverbyte=DRIVER_OK
scsi 16:0:0:252: rdac: Detached
sd 16:0:0:253: [sdr] Synchronizing SCSI cache
sd 16:0:0:253: [sdr] Synchronize Cache(10) failed: Result:
hostbyte=DID_NO_CONNECT driverbyte=DRIVER_OK
scsi 16:0:0:253: rdac: Detached
sd 16:0:0:254: [sds] Synchronizing SCSI cache
sd 16:0:0:254: [sds] Synchronize Cache(10) failed: Result:
hostbyte=DID_NO_CONNECT driverbyte=DRIVER_OK
scsi 16:0:0:254: rdac: Detached
mlx5_core 0000:af:00.1: Shutdown was called
mlx5_core 0000:af:00.0: Shutdown was called
```