



无法通过 xPermissionsDenied 访问节点 UI

https://kb-cn.netapp.com/Legacy/NetApp_HCI/Management_services_for_Element_Software_and_Net...

Updated: Mon, 20 Apr 2026 15:21:31 GMT

适用于

- Element Software
- SolidFire 节点

问题

尝试访问节点 UI 或运行任何 API 调用时收到输出："xPermissionsDenied"

