



ONTAP升级或重新启动后集群端口关闭

https://kb-cn.netapp.com/on-prem/ontap_OS/OS-KBs/Cluster_ports_down_after_ONTAP_upgra...

Updated: 周五, 11 7月 2025 14:56:51 GMT

适用场景

- ONTAP 9
- · 自动化无中断升级(ANDU)
- 带有板载集群端口的FAS或AFF或ASA系统
- 有交换机或无交换机集群

问题描述

- 在ONTAP升级期间、首次重新启动到新的ONTAP版本后、集群端口显示为关闭状态。 在计划内或计划外重新启动给定节点时、也可能会出现这种情况。
- storage failover show 将显示以下状态问题描述:

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information contained herein may be used solely in connection with the NetApp products discussed in this document.'

Node	Partner	Possible	e State Description
node-01	node-02	true	Connected to node-02, Partial giveback
node-02	node-01		Connected to node-01. Waiting for cluster applications to come online on the local node. Offline applications: mgmt, vldb, vifmgr, bcomd, crs.

• cluster image show-update-progress 将显示一个典型输出:

Cluster::*> cluster image show-update-progress

	Estimated	Elapsed	
Update Phase	Status	Duration	Duration
Pre-update checks	completed	00:10:00	00:01:04
Data ONTAP updates	paused-on-erro	01:32:00	0 1 days 02:39

Details:

Node name	Status	Status Description
node-01	waiting	
node-02	failed	cor: Node "node-02" is not in
	"connect	ed" state after giveback.
	Action:	Use the "storage failover
	show" co	ommand to verify that node
	"node02"	' is in the "connected"
	state.	

Status: Paused - An error occurred in "Data ONTAP updates" phase. The update cannot continue until the error has been resolved. Resolve all issues, then use the "cluster image resume-update" command to resume the update.

• UP节点的cluster ring show 输出将无法列出受影响节点的条目:

::*> cluster ring show

Node	UnitName	Epoch	DB Epoch	DB Trnxs	Master	Online
node-01	mgmt	6	6	41	node-01	master
node-01	vldb	6	6	3	node-01	master
node-01	vifmgr	6	6	30	node-01	master
node-01	bcomd	6	6	1	node-01	master
node-01	crs	6	6	1	node-01	master

Warning: Unable to list entries on node node-02. RPC: Couldn't make connection [from mgwd on node "node-01" $\,$

(VSID: -1) to mgwd at 169.254.200.103]

这些环将在受影响节点本地显示offline:

::*> cluster ring show

Node	UnitName	Epoch	DB Epoch	DB Trnxs	Master	Online
node-02	mgmt	0	3	1165	_	offline
node-02	vldb	0	3	39	_	offline
node-02	vifmgr	0	3	248	-	offline
node-02	bcomd	0	3	16	_	offline
node-02	crs	0	3	8	_	offline
node-02	mgmt	-	_	-	_	_

6 entries were displayed.

Warning: Unable to list entries on node node-01. RPC: Couldn't make connection [from mgwd on node "node-02"

(VSID: -1) to mgwd at 169.254.200.103]

5 entries were displayed.