



---

## 由于严重的 NVRAM 电池故障，AFF-A800 关闭电源

[https://kb-cn.netapp.com/on-prem/ontap/OHW/OHW-KBs/AFF-A800\\_powers\\_off\\_due\\_to\\_Critical\\_NVR...](https://kb-cn.netapp.com/on-prem/ontap/OHW/OHW-KBs/AFF-A800_powers_off_due_to_Critical_NVR...)

Updated: Sat, 25 Apr 2026 10:18:28 GMT

### 适用于

- ONTAP 9
- AFF C800
- AFF A800

## 问题

电池传感器不可读，电池不存在或无法访问。