



如何许可 Brocade FC 交换机端口

适用于

- Brocade FC 交换机
- Brocade 许可
- Brocade 按需端口 (POD)

说明

- 如何检索 Brocade 光学套件事务密钥
- 当 POD/光学套件发货时,它们可能不附带用于激活 POD 许可证的事务密钥
- 必须在为交换机生成许可证之前在线检索事务密钥

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information contained herein may be used solely in connection with the NetApp products discussed in this document.'