



是否可以使用"STATIST量show"命令将FlexGroup卷作为一个完整卷输出总值？

https://kb-cn.netapp.com/on-prem/ontap/Ontap_OS/OS-KBs/Is_it_possible_to_use_the_statistics_volu...

Updated: 周五, 11 7月 2025 13:15:46 GMT

适用场景

ONTAP 9

问题解答

不可以。以下是 目标卷为Flexgoup卷时的示例：

```
ontap913::> statistics volume show -volume fg_src*
```

```
ontap913 : 5/9/2024 17:32:15
```

	*Total	Read	Write	Other	Read	Write	Latency	
Volume	Vserver	Aggregate	Ops	Ops	Ops	Ops	(Bps)	(Bps)

(us)

fg_src__0004	svm1_ontap913	aggr2_node1	0	0	0	0	0	0	0
fg_src__0003	svm1_ontap913	aggr1_node1	0	0	0	0	0	0	0
fg_src__0002	svm1_ontap913	aggr2_node1	0	0	0	0	0	0	0
fg_src__0001	svm1_ontap913	aggr1_node1	0	0	0	0	0	0	0

追加信息

[statistics volume show](#)